



Quick Install Guide

HandyTone 286

HandyTone-286 is a VoIP Analog Telephone Adaptor designed to work with an ordinary analog telephone. The following photo illustrates the appearance of a HandyTone-286.



Step One - Connect an Ethernet cable (included) to the RJ45 Ethernet port on the back of the HandyTone-286. Connect the other end of the cable to a port on your router if you have one. If you do not have a router then you can plug the cable directly into your Cable or DSL modem.

Step Two - Connect the RJ-11 cable from your phone into the phone port on the back of the HandyTone-286

Step Three - Plug the small round end of the included power adapter cable into the power port on the back of the HandyTone-286. Plug the power adapter into a wall socket or your power strip.

Important - Once power is applied wait until the red light on top of the HandyTone-286 stops blinking. (Usually about 20 blinks).

Step Four - Pick up your phone handset and listen for a dial tone. Once a dial tone is heard you can start making calls.

How To Dial - You always dial the (Country Code) - (City or Area Code) - (Number)
As 1-800-555-1212 or for India it would be 91-98-55555555

