

# NARGLE®

## Quick Install Guide HandyTone 486



Step One - Connect an Ethernet cable (included) to the WAN port on the back of the HandyTone-486. Connect the other end of the cable to a port on your router if you have one. If you do not have a router then you can plug the cable directly into your Cable or DSL modem.

Step Two - Connect the RJ-11 cable from your phone into the phone port on the back of the HandyTone-486

Step Three - Plug the small round end of the included power adapter cable into the power port on the back of the HandyTone-486. Plug the power adapter into a wall socket or your power strip.

Important - Once power is applied wait until the red light on top of the HandyTone-486 stops blinking. (Usually about 20 blinks).



Step Four - Pick up your phone handset and listen for a dial tone. Once a dial tone is heard you can start making calls.

How To Dial - You always dial the (Country Code) - (City or Area Code) - (Number)

As 1-800-555-1212 or for India it would be 91-98-55555555

No Router? - You can plug the HandyTone-486 into your Cable or DSL modem using the instructions above then, plug one end of a standard Ethernet cable into the LAN port on the back of the HandyTone-486 and the other end into the Network Interface port on your computer. Your computer will need to be configured to obtain an IP address automatically. You will need to restart your computer to complete the connection.